说明书 尺寸:120x90mm 装订:骑马钉


128g双铜纸4色双面印刷


封底

封面
















 Left button:left button function 2. Right button:right button function3. Middle button:middle button function 4. Back button: back to previous page 5. Forward button: enter to next page 6. DPI+: switch to higher DPI value, without loop switch
7. DPI-: switch to lower DPI value, without loop switch 8. Three bursts: Equivalent to click the left key for 3 times 9. Fire key: Speed rate can be adjust in software for the mouse key. 10. Combination key: customize Ctrl, Shift, Alt, Win and any of the keyboard buttons to combine button functions(support 3 reassembles farthest, such as Ctrl+A+B)

11. Multimedia function: Media Select, Previous, Next, Stop, Play/Pause, Mute, Volume+, Volume-, Mail, Calculator functions.

12. Word office:Copy, Paste, Cut, Select all, New, Save, Print, Open, Undo.

13. Windows:My computer, Close window, Display desktop, Run, Minimize, Maximize. 14. DPI: DPI+, DPI- and DPI loop 15. Locking DPI, from 200-1200 to lock any of the DPI values. 16. The return rate of mouse : with 125HZ/250HZ/500HZ/1000HZ to choose 17. The movement speed of mouse: to adjust the movement speed of mouse
18. The scroll wheel speed of mouse: to adjust the scroll wheel speed of mouse 19. The double-click speed of mouse: to adjust the double-click speed of mouse.
20. Mouse LOD Height: Mouse silent height (the cursor stops responding when the mouse is raised a few millimeters).


21. Debounce Time: Setting the key debounce time.

Macro definition


Macro management can record any keys of keyboard, the time of keys reaction and the number of keys cycles.

a. Click 【create】 to create a new file, such as a, b, c...
b. Select whether to increase the delay and the times of cycles
c. Click 【start recording】 and start recording any keys of keyboard. The keys you recorded will display in the macro edit box
d. After the recording, click "stop recording"
e. To revise the recording content, please make the following changes in the macro options:
Choose to insert the event: insert relevant content in the selected location
Delete: Delete the selected content
Modify:Modify the delay value and input button again

f. After recording is completed ,just exit the macro recording interface, no need to click the confirmation keys
g. Execute a macro, such as the mouse button ④ key set to "macro functions", after recording is complete, press the mouse④key to play the recorded content







产品名称:	MS979WB说明书
材 质:	128g双铜
装订方式:	骑马钉
尺 寸:	120*90(mm)
设计人:	设计部——何筱杰
定稿日期:	2024. 02. 29